
Randall

RG-30

OWNER'S MANUAL




- DUAL FUNCTION INPUT JACKS:
 INPUT No.1 6dB greater than Input No.2
 INPUT No.2 Reduced gain to accommodate
 extra-strong signals
- VOLUME CONTROL
 To regulate input gain
- REVERB CONTROL
 To regulate built-in circuitry.
 Reverb can be turned on and off by
 means of a footswitch. (See rear
 panel highlights).
- TREBLE CONTROL
- BASS CONTROL

Note: Since no one can determine exactly what sound will be desired in all instances, it is best to experiment with the tone controls to produce the desired response. If all tone controls are set at 0 there will be no sound!

A Master Sustain Control is provided for added flexibility.
For a clean sound the Master Sustain Control should be set at 10 while using the Volume Control to achieve the desired volume level.
For an overload-like sustain sound, the Master Sustain Control should be at a relatively low setting such as "5". The Volume Control should then be set for the desired sound. The Master Sustain can then be used to raise or lower the overall volume level.

By experimenting with both settings you should be able to achieve any sound from studio clean to rock and roll dirty.



- @ PILOT LIGHT
- POWER POLARITY SWITCH
 Three position switch provides a
 means of turning amplifier on and
 also reversing power polarity.
- CIRCUIT BREAKER
 The Circuit Breaker is actually a
 mechanical fuse and protects the
 amplifier from extreme overload
 conditions. Pushing in on the
 Red Circuit Breaker Button will
 set it. If the Circuit Breaker
 does trip and cannot be reset,
 refer to a qualified technician.
- FOOTSWITCH JACK
 For hands-free on-off operation
 of Reverb.
- EXTERNAL SPEAKER JACK
 Provided to connect an external
 speaker of 8 ohms.
- C PRE-AMP OUTPUT JACK
 Provided to supply signal for
 driving additional amplifiers or
 for direct recording.
- M SERIAL NUMBER
 Be sure to send in your
 Warranty Card.